SHARE THE VIEW:
Take a video using the product with #XMAXVAPORIZER and we'll share it with our global family.

@XMAX.VAPORIZER

@XMAXVAPORIZER.CN

BATTERY HEALTH NOTE
PLEASE DO NOT TIP THE PRODUCT AWAY OR LEAVE IT FOR EXTENDED PERIODS OF TIME WITH A LOW CHARGE. IF THE BATTERY FALLS BELOW 8% AND IS LEFT THAT WAY THEN IT WILL NO LONGER ACCEPT A CHARGE.

1

XMAX V4 PRO

INSTRUCTION MANUAL

DISCLAIMER

Thank you for purchasing the XMAX V4 PRO. To ensure the best experience, please read and understand the instructions fully before your first use of the XMAX V4 PRO. We strongly recommend you keep these instructions for future reference.

We hope you enjoy the excellent quality and performance of your new XMAX V4 PRO.

User must be of legal age within any given jurisdiction to purchase or use the XMAX V4 PRO. Use the product in moderation. This product should not be used by a child, adolescent, or woman. Pregnant or breastfeeding women should not breast feeding and those with life threatening illnesses without first consulting a doctor.

California Prop 65 WARNING: This product contains chemicals known by the state of California to cause cancer

2

birth defects or other reproductive toxicity. The vaporized aerosol of chemicals known to cause respiratory or other diseases and in some cases are irreversible. If needed contact your local poison control center, USA: (800) 222-1222.

Note that the XMAX V4 PRO is not a medical device and is not intended to administer medicinal or illegal substances of any kind. Illegal, dangerous, treat or prevent any diseases or other conditions.

Any illegal use of this device could subject the user to severe fines, penalties and/or imprisonment under the law of their land(or other) jurisdictions.

THIS PRODUCT DOES NOT CONTAIN ANY BOTANICAL MATERIAL.

3

XMAX V4 PRO OVERVIEW

4

OPERATION GUIDE

Notice: Please remove protection lids in battery compartment before using.

1. CHARGE

Fully charge device before first use. Please use provided USB-C cable to charge your device.

The display screen will show charging and be always on when fully charged.

5

2. LOAD

How to use the oven:
Remove the magnetic mouthpiece top and choose which botanical substance is best for you. Due to the amount of delicate technology, please be gentle when packing the oven and/or inserting the oven cup and/ or cleaning.

6

XMAX V4 PRO CONTENTS

USB-C Cable	4 Airchop Carbon Fiber Pieces
Cleaning Tool	Cleaning Cloth
Brush	3 Cotton Swabs
4 Metal Screens	

Note: please find these cup separately for use with different herbs.

SPECIFICATIONS

Battery Capacity	18650 2.5Ah 20Amen
Charging Voltage/Current	5V/ 1A
Discharge Voltage	3.7-4.2V
Cup Material	CNC Pro Surface 2 times Anodized
Temperature Range	40°C-200°C (104°F-392°F)
Outer Material	Metal
Glass Material	CNSD
Outer Finish	Matte Anodized
Accidental Single Puff Protection	Yes
Size	4.7" x 1.6" x 0.8" / 119mm x 41mm x 20mm

Botanical Flower:
Loosely pack the ground substance into the oven cup, make sure the substance beyond the top of the oven chamber.

Dosing capsule:
Open the cap of the dosing capsule, load the desire substance into the dosing capsule, then insert the dosing capsule into the oven chamber.

Use the cup or load the cup chamber
The recommended 1g is approximate half of the cup capacity and the

7

3. POWER ON/OFF

Click power button 3 times, the XMAX V4 PRO will be powered on and begin to

8

ON DEMAND Mode: Keep pressing the power button" to heat up "set" button as well, the device will vibrate when reach the heating temperature and ready for use.

The device will vibrate 3 times and auto suspend heating after 30s, please keep pressing the "power button" again to continue heat for an additional 30s.

5. TEMPERATURE SETTINGS

Press or hold the "up button" to increase temperature or hold the "down button" to decrease temperature

Click to change by degree, hold to change quickly

Temperature Range: 200°-200°C (392°-392°F)

9

6. TIMER SWITCHOVER

10

7. FAHRENHEIT AND CELSIUS SWITCHOVER

To switchover to Fahrenheit, hold the "up button" and "down button" at the same time for 2 seconds.

11

8. MODE SWITCHOVER

To switchover to "ON DEMAND" mode, click the "up button" and "down button" simultaneously once.

The device will automatically power off if not being used within 120 seconds. Click the "up button" and "down button" simultaneously once. Then switchover to "SESSION" mode.

9. OLED DISPLAY

10

10. SESSION LEVEL

Hold the up button and down button and power button simultaneously once.

11

11. ADJUST AIRFLOW

Push the air adjustment button up and down to adjust the smoothness of the airflow.

12

12. CLEANING & MAINTENANCE

Please clean the XMAX V4 PRO working optimally and maintaining the purest tastiness and flavor of your herbs, which come in contact with material or vapor as cleaning regularly.

All removable parts can be disassembled for optimal cleaning.

Mouthpiece & filter
Gently pull the mouthpiece to remove it. It can be cleaned with soap and water.

For deep cleaning, immerse all pieces in isopropyl alcohol for 30 minutes. Rinse thoroughly with clean water and dry before reassembling.

1. Metal oven cleaning: use brush to sweep inside and cotton swab dipped in isopropyl alcohol.

13

* Tip: Perform a burnoff cycle at max temp for 2 minutes after cleaning.

2. Replace the oven mesh screen.

(1) Please use the cleaning tool slowly remove the mesh screen along the wall of the oven.

14

After using the XMAX V4 PRO or charging, please allow the device to cool down before storage. It should be stored in a clean, dry place protected against the effects of weather and out of the reach of children and pets. If you have any concerns or if there is any problem, please switch off the XMAX V4 PRO and/or remove it from the charger immediately. Do not try to remedy any defect yourself. Contact our customer service directly at support@nsgreenco.com.

15

(2) Put the mesh screen into the oven, then use the cleaning tool to press the screen in the specified position.

16

NOTE:

DO NOT TOUCH THE HEATING ELEMENT IMMEDIATELY AFTER USE

DO NOT CLEAN THE WHOLE DEVICE WITH WATER OR SUBMERSIE.

DO NOT INJECT ANY LIQUID OR OIL INTO THE METAL OVEN.

MAKE SURE TO DEACTIVATE THE DEVICE BY LOCKING. MAKE SURE IT HAS NOT BEEN USED FOR AT LEAST 30 MINUTES AND IS COMPLETELY COOLED OFF.

WARNING:
HOT COMPONENTS

USE ORIGINAL BATTERIES ONLY

17

SAFETY

Prior to your first use, please read and fully understand the instructions including the safety information. We recommend that these instructions be kept for future reference. Failure to follow warnings may result in a safety hazard including electric shock, fire, property damage, bodily injury or death.

AGE:
You must be of legal age in your jurisdiction to purchase or use the XMAX V4 PRO. For adult use only.

USE:
Never use the product before reviewing the manual in its entirety. If any section or topic is unclear prior to use, please contact customer service for clarification.

This product should not be used by children, women who are pregnant or breast feeding or those with life threatening illnesses without first

18

consulting a doctor. It is recommended that all users consult a doctor prior to use with any chronic illness or concentrate. Note that the XMAX V4 PRO is not a medical device and is not intended to diagnose, cure, treat, or prevent any diseases or other medical conditions. XMAX V4 PRO is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties, and/or imprisonment under the laws of your land jurisdiction.

DAMAGE
Immediately discontinue use of the product if the vapor mist is damaged in any way including but not limited to: dents, overheating, unusually restrictive airflow, and/or electrical malfunctions. Do not use the product if it is damaged by disassembly of non-replaceable parts (mouthpiece, filter, Packing Tool, and Removable Battery. Please contact customer service for help with any damaged unit.

LIMITED WARRANTY

The product is warranted for a period of 12 months from purchase with receipt, or 12 months from date of manufacture without receipt against defects in manufacturing, workmanship, and materials. This device is designed for the use of legal herb and concentrates only. Any use of the XMAX V4 PRO with illegal substances will void the warranty.

This warranty covers only the electronic basic This warranty does not warrant malfunctions, battery cell, screaming tool and/or other detachable parts. The warranty does not apply to damage caused by accident, abuse, misuse, natural disaster, user error, or use outside the intended use described in the manual. Use outside the intended use as described in this manual also includes any tampering with device in any way, including but not limited to modification to other functionality, or modification to alter appearance.

The warranty also does not apply to

19

All batteries may explode or burst into flame if used improperly or mistreated. Do not disassemble, puncture tamper, cut, crush, short-circuit, incinerate or expose to water. Keep in high temperature above 60°C or 140°F. It is recommended that you remove the magnets as well as the proper procedures for handling all batteries. Do not dispose of in normal trash containers nor litter the environment.

Please recycle or dispose according to local safety regulations law. (Suggested to cover terminals with proper insulating tape before disposal.)

WARNING ⚠
THIS PRODUCT IS NOT INTENDED FOR INGESTIME. PRODUCT IS DESIGNED FOR LEGAL BOTANICALS AND CONCENTRATE USE ONLY.PRODUCT DOES NOT CONTAIN ANY BOTANICALS OR CONCENTRATE MATERIALS. KEEP DEVICE AWAY FROM CHILDREN AND PETS.

20

cosmetic damage including but not limited to dents, scratches/chips to finish, and/ or broken plastic parts.

Normal product wear and tear is not covered under warranty. Normal performance degradation of batteries is also not covered by the warranty.

To make a warranty claim, please contact customer support at support@nsgreenco.com. The original bill of sale, authenticity code, pictures or videos, and any serial numbers are required to redeem the warranty.

At the manufacturer's discretion, warranty service will be provided by repair of the product or exchange of the product and/or part with a new or functionally equivalent product/part.

21

CUSTOMER SUPPORT

For any question or concerns with the product, you are welcome, please contact customer support at support@nsgreenco.com. We will do our best to provide a response within two (2) business days after receipt of written notice.

22